

Kirby Task chair



1. Seat height adjustment: Lift lever (1) to raise/lower seat height.
2. Seat angle adjustment: Lift lever (2) to alter seat tilt position. Push lever down to lock in desired Position. Leaving lever in “up” position will allow free float option. This operates in conjunction with or independently of back angle adjustment.
3. Back angle adjustment: Lift lever (3) to adjust the back angle. Release to lock.
4. Body weight tension adjustment: When seated, wind the knob(4) clockwise to loosen, anticlockwise to tighten.
5. Seat slide adjustment: Lift lever and slide the seat either forwards or backwards to increase or decrease the seat depth.
6. Back height adjustment: While seated, lift the back (6) manually to your desired height. The mechanism is a ratchet which ‘clicks’ at various set heights. Once the back reaches its full height, it will slide back to the bottom, to start again.
7. Arms: Lift the button (7) to raise or lower the arms.